



Terminal Maintenance Reference Guide

Before proceeding, read the following instructions on how to properly install and care for your new equipment.

- ☐ Plug-in phone line and PIN pad **BEFORE** plugging the terminal into a power strip/surge protector. Failure to do so, specifically for any PIN pads, will erase all PIN pad encryptions.
- ☐ **ALWAYS** plug the terminal into a power strip/surge protector. Failure to do so will void any applicable warranties.
- ☐ If you experience a power surge, replace the power strip/surge protector immediately.
- ☐ **NEVER** turn off the terminal. Doing so may damage the equipment and result in a loss of memory.
- ☐ Routinely inspect cords to make sure that they're not damaged, cracked, or frayed.
- ☐ Do not place the terminal in or near water. If water is spilled on the terminal, gently clean it up with a towel.
- ☐ Routinely clean the equipment by using alcohol or a gentle household cleaner on a towel. Do NOT pour or spray cleaning agents directly onto the equipment.
- ☐ Handle the terminal and PIN pad with care. Do not drop, shake, or misuse the buttons. Keep away from areas where food and beverages are frequently handled.



Manual para Mantener su Máquina de Tarjeta de Credito

Antes de seguir, por favor lea las instrucciones en como instalar y cuidar su nueva máquina.

- ☐ Enchufe la línea telefónica y PIN pad **ANTES** de enchufar la máquina en la regleta de enchufes/ protector contra sobrecarga. Si no haces esto, se puede perder la encrypcion del PIN pad.
- ☐ **SIEMPRE** enchufe la máquina en la regleta de enchufes/protector contra sobrecarga o no garantía aplicará.
- ☐ Si experiencias un sobrecarga, cambie la regleta de enchufes/protector contra sobrecarga inmediato.
- ☐ **NUNCA** apage la máquina. Apagando la máquina puede dañarlo y perder la memoria.
- ☐ Habitualmente, inspecta los cables para asegurar que no están dañados, rajados, o deshilachados.
- ☐ No coloques la máquina cerca o en agua. Si agua se derrama en la máquina, seca la máquina con una toalla.
- ☐ Habitualmente limpie la máquina usando alcohol o un limpiador de casa en una toalla. Nunca heches alcohol o limpiador de casa en la máquina directamente.
- ☐ Ten cuidado con la máquina y PIN pad. No dejes que la máquina y PIN pad se caiga o agite. No dañe los botones. No acerques comida o bebidas al equipamiento.

Si tienes algunas preguntas en como instalar o cuidar su nueva máquina, por favor llame la ayuda técnica a (800) 966-5520, Opción 3.

TURN OVER FOR ENGLISH 